

## NEW PRODUCT RELEASE

For Immediate Release  
January 23, 2008

Contact: Applications Engineering

# See it Dispense. See it Cure. See the Solution. DYMAX Introduces See-Cure™ Technology

If to see is to believe, then DYMAX has developed the world's most persuasive light-curing adhesive technology for industrial assembly processes. See-Cure™ technology addresses the two most-often asked questions about light-curing products: How do I know I've dispensed enough adhesive? *and* How do I know when it is cured?

DYMAX adhesives that are formulated with new *See-Cure* technology are bright blue in color in the uncured condition. This makes them easy to see on the surface of substrates, in deep wells, or when sandwiched between two layers of materials. The blue-colored *See-Cure* adhesives will not permanently stain the component surfaces that they contact. Because the blue color is extremely visible, simple vision systems can be incorporated into assembly processes prior to curing in order to easily identify adhesive coverage and profile.

*But, See-Cure's blue color is only temporary!*

The adhesive's blue color becomes the visible indicator that identifies when sufficient light energy has been provided to the adhesive

---

DYMAX Corporation – 318 Industrial Lane - Torrington, CT 06790 - Phone: 860-482-1010 - Fax: 860-496-0608 - E-mail: [info@dymax.com](mailto:info@dymax.com) - [www.dymax.com](http://www.dymax.com)

DYMAX Europe GmbH - Trakehner Strasse 3 - D-60487 Frankfurt am Main - Germany - Phone: 0049-69-7165-3568 - Fax: 0049-69-7165-3830 - E-mail: [dymaxinfo@dymax.de](mailto:dymaxinfo@dymax.de) - [www.dymax.de](http://www.dymax.de)

DYMAX UV Adhesives & Equipment (Shenzhen) Ltd – Unit 807, Talfook Building, No. 9 Shi Hua Road, Futian Free Trade Zone, Shenzhen, China 518038 Phone: 86.755.83485759 - Fax: 86.755.83485760 - E-mail: [simon\\_ang@dymax.com](mailto:simon_ang@dymax.com) - [www.dymax.com.cn](http://www.dymax.com.cn)

DYMAX Asia (HK) - Unit 1006, 10/F., Carnarvon Plaza, No. 20, Carnarvon Road, T.S.T., Kowloon, Hong Kong - Phone: 852-2460-7038 - Fax: 852-2460-7017 - E-mail: [simon\\_ang@dymax.com](mailto:simon_ang@dymax.com) - [www.dymax.com.cn](http://www.dymax.com.cn)

DYMAX®, Light-Weld®, Light-Welder®, Multi-Cure®, Ultra Light-Weld®, MEDI-CURE®, MD® and *SPEEDMASK*® are registered trademarks of DYMAX Corporation

